


TRK58A / TRK58B / TRK42A / TRK42B TREKKER OUTBACK TOP CASE



1	<b>ZOBK58ACM</b>	OBK58A assembled Top Shell
	<b>ZOBK58BCM</b>	OBK58B assembled Top Shell black
	<b>ZOBK42ACM</b>	OBK42A assembled Top Shell
	<b>ZOBK42BCM</b>	OBK42B assembled Top Shell black
2	<b>ZOBK58AFM</b>	OBK58A assembled Bottom Shell
	<b>ZOBK58BFM</b>	OBK58B assembled Bottom Shell black
	<b>ZOBK42AFM</b>	OBK42A assembled Bottom Shell
	<b>ZOBK42BFM</b>	OBK42B assembled Bottom Shell black
3	<b>Z8024MR</b>	Lock set

4	<b>Z115R</b>	Stop bag opening yarn, 2 pcs.
5	<b>Z8098R</b>	Internal soft carpet
6	<b>Z1782R2</b>	Bolt with springs
7	<b>Z8025R</b>	Sistema di sgancio completo montato
8	<b>SL101</b>	Security Lock key, including bush and under lock platelets